

UITSCHUIFSTAPPEN														
DEEL	1	2	3	4	5	6	7	8	9	10	11	12	13	14
D	500	1000	1500	2000	2500	3000	3500	4000	4500	5000	—	—	—	—